



User Guide of Temperature Controller

Product overview

Temperature controller of heat radiator is powered by dry battery, without wiring, a convenient in mounting, is used to control the temperature of water-heated radiator. When providing comfortable temperature, it can reduce energy waste and saves user's heating cost. This product, with a low-in-power consumption and great energy saving, the LED display, the LED light, the light, can be used alone or added to the graffiti intelligence APP so that it can become an intelligent temperature controller which can be set and checked in the APP.

After joining graffiti intelligence system, the mode can be selected in APP. In the temperature, child lock and window-opening detection function can be set. Any connection of equipment, such as interval setting of temperature, would be synchronized to APP.

Technical specifications

Power Supply:	3 x 1.5 V alkaline AA batteries (not included)
Standby Current:	6µA Min
Protection Degree:	IP20
Ambient Temperature:	0~50°C
Surface Temperature:	90°C Max (at the radiator)
Connection:	M30 x 1.5mm
Linear Travel:	6mm
Dimensions(W x H x D):	54mm x 89mm x 54mm
Weight:	139g

Installation of the Adapters

User Guide of Temperature Controller

Method to correctly mount adapter

Method to correctly mount adapter	Applicable to flow valve	Applicable to Duct valve

Installation instructions

1: Pull the knob in the direction of the arrow with your hand.
2: Pull out shell with right hand toward the arrow.
3: Turn to the polar direction as indicated in battery tank to load 3 AA alkaline batteries.
4: Install the shell and knob at the marked position to complete the installation.

Device Overview

User Guide of Temperature Controller

To minimize the influence of heat radiator's own calorie on temperature controller it is suggested to mount as per the following method

Operation

User Guide of Temperature Controller

Before temperature controller is mounted on valve, load 3 batteries as per the polar direction as indicated in battery tank. In the meantime, you would feel the slight vibration of temperature controller, which belongs to the necessary component of automatic detection.

At the specific time period of temperature controller, the temperature controller will automatically detect the temperature control valve and find the exact opening position of valve. The automatic detection function could achieve efficient utilization of calorie and more accurate control of temperature as far as possible.

After the installation of temperature controller at the heat radiator valve. When slightly pushing forward, clockwise rotate interface nut till tightening, with the maximum moment of 5N.m current temperature is displayed, and the mounting is finished. Turn the knob to adjust the temperature.

Automatic detection

User Guide of Temperature Controller

After temperature controller is mounted, the system would be automatically connected to the network. In this process, you may find that temperature controller can't be connected to the network, which belongs to the necessary component of automatic detection.

At the specific time period of temperature controller, the temperature controller will automatically detect the temperature control valve and find the exact opening position of valve. The automatic detection function could achieve efficient utilization of calorie and more accurate control of temperature as far as possible.

If necessary, please take out battery and wait for 30s, then release battery to activate the mounting mode so that temperature controller can run the automatic detection function. At this time, the temperature control valve shows LA

About valve

Operating Instructions

User Guide of Temperature Controller

Shutoff: When the temperature is adjusted to the minimum temperature and then decreases, turn it off.

Power on: Turn on the machine by rotating and adding temperature in the shutdown state, or short press the mo^{de} button.

Build-in big-front LED display screen facilitates check. Battery's endurance period lasts for one heating season, worry-free! The graffiti WiFi wireless communication protocol is adopted, safe, reliable and convenient.

Window-opening detection

User Guide of Temperature Controller

Startup: room temperature decreases by 3°C within 5 minutes, stop heating. **Clear:** room temperature rises by 3 degrees/48 minutes later/manual/three ways. After the window opening mode is turned on, one of these three conditions can trigger to exit the window opening mode.

- If your open window switch is off, the device will not detect the drop of temperature and stop heating.

Anti-freeze function

User Guide of Temperature Controller

If the cooling fan's valve isn't completely on one time within two weeks, valve would be blocked due to excessive scale, and the cooling fan won't be used. To guarantee that the cooling fan can be used normally, controller would automatically switch on valve completely one time every two weeks and run for 30s. During that period.

Product characteristics

User Guide of Temperature Controller

4 working modes, —programming mode, —manual mode, —temperature programming mode, OFF—OFF mode.

Error code

User Guide of Temperature Controller

Troubleshooting and maintenance

Error code	Problem
E1	Stroke fault detection
E2	Low battery
E3	Temperature sensor abnormality
E4	Reminder to open the window
E5	Indoor low temperature alarm

APP download

Phone Port Operation Instruction

Preparation before Network Configuration

2. Account registration. If you have no APP account, you can select to register or log in via message authentication code. Click "create new account" to enter the Privacy Policy page of graffiti intelligence platform. You can also select the country/region manually. After entering your mobile phone number or email address, click "get verification code". Enter the received verification code, then enter the password, and click "Finish" to register successfully.

1.Download APP
For iOS system: Login in App Store, search "Tuya Smart", you can download it on your iPhone.
For Android system: Login in Google Play, search "Tuya Smart" you can download it on your phone.
Or scan below code to download:

User Guide of Temperature Controller

1.Turn on your mobile phone's Bluetooth and WiFi function. Connect your mobile phone to **your 2.4GHz WiFi** (please make sure your mobile phone connect to 2.4GHz Wi-Fi and the 2.4GHz Wi-Fi name and password contain only numbers and letters and not special symbols).

2.Activate the thermostat WiFi module. When the thermostat is turned off, press and hold the Middle button for 3 seconds, the icon flashes on the thermostat display, and the thermostat enters the code matching state.

3.Add Device

There are 2 ways to add a device.
Method 1: Enter the Tuya APP. The main page automatically pops up "Device to be added" (as picture 1) and click "Add".

User Guide of Temperature Controller

Method 2: Enter the Tuya APP. Click "+" on the upper right corner of the APP homepage and enter the "Add Device" interface. It will prompt: find the device to be added (as picture 3) and follow the prompts.

User Guide of Temperature Controller

4.Enter WiFi information
Enter the name and password of the **2.4GHz WiFi**
If your phone is already connected to WiFi, then the name and password of the WiFi you are connected to will be automatically filled in here.
Follow the prompts to the next step, you can see the device is being added, and after a few seconds, you will see that the device is added successfully (the length of time will depend on the strength of the WiFi signal).

User Guide of Temperature Controller

1.Turn on your mobile phone's Bluetooth and WiFi function. Connect your mobile phone to **your 2.4GHz WiFi** (please make sure your mobile phone connect to 2.4GHz Wi-Fi and the 2.4GHz Wi-Fi name and password contain only numbers and letters and not special symbols).

2.Activate the thermostat WiFi module. When the thermostat is turned off, press and hold the Middle button for 3 seconds, the icon flashes on the thermostat display, and the thermostat enters the code matching state.

Enter the Tuya APP. Click "+" on the upper right corner of the APP homepage. Click "Add Device" and find the TRV in "Small Home Appliance" (as picture 4).

User Guide of Temperature Controller

Wait a few seconds, you can see the device is being added, and after a few seconds, you will see that the device is added successfully (the length of time will depend on the strength of the WiFi signal).

User Guide of Temperature Controller

Display of temperature controller APP interface

If you encounter any problems during the use of the product, please feel free to contact us through the purchase platform, we will try our best to help you.